

EZ CARNIVAL TENTS



Set-Up Manual

Manufactured by Interactive Game Warehouse
www.interactivegamewarehouse.com

Version 2.1 February 5, 2012

Carnival Tent Set-up

Congratulations on your EZ Carnival Tent Purchase. You have made the first step in distinguishing you from your competition. The EZ Carnival tent is not only easy to use, but it is also quick if you follow the tips and tricks outlined in this manual. Lets get started!

Step 1



Image 1

Always set-up and tear down on a clean surface to prolong the life of your tents. Any clean tarp will work just fine or you can purchase a weighted tarp from www.interactivegamewarehouse.com

Step 2

Select the 3 longest poles (8') poles and attach the 1" EMT (Electrical Metal Conduit) couplings as shown in image 2




Image 2

Step 3



Next Take the three shortest poles and lay them out as shown in image 3. This will help speed up the process when assembling the tent.

Step 4



Now place the short poles into the center pole with couplings making the A-Frame shape. Do this on both sides.

Step 5

Now Rotate the outside couplings and poles to connect to the other end of the short Poles as shown. Now make sure that all of this finger bolts are securely fastened.



Step 6



Now you are ready to install your tent top. We think it is a good practice to always install the tent with as little contact to the ground as possible. This will not only extend the life of your tent but will reduce the amount of cleaning that needs to be done. Start by unrolling the tent on the center pole of the tent frame.

Step 6



Now simply stretch the tent over all 4 corners of the frame. The tent should be a tight fit once you get to the last corner. This will ensure a nice looking finish.

Step 7




Now simply insert the legs into the remaining slot on the tent. It's ok if the frame twists when doing this it will not hurt your tent. Do this on all 4 corners.

Step 8



Now insert the .5" poles into the top pocket on all the side walls.

Step 9



Connect the .5" poles to the first set of anchor points between two sets of legs. Do this for all 4 side walls. The side walls will share d-rings, you should have 2 poles connected to each d-ring if you are using all 4 side walls.

Step 10



Next connect the bottom bungee to the bottom d-ring on the leg. this will pull your sidewall tight and keep it from moving.

Step 10



After all the walls are connected you may use the provided tent straps to tighten the tent top for a nice, tight fit. First insert the loop on the strap around the bottom of the tent leg pole. Next run the strap all the way up to the tent top corner, through the d-ring on the tent. Continue the strap down to the 2 d-rings on the strap and weave them through to make a tight connection. Pull on the strap until desired tension. Repeat this step on all 4 corners. Your tent is now ready to be staked down. Use stakes or sand bags to secure your tent. **DO NOT OPERATE** in winds over 15 mph.